


# Rim<sup>®</sup>


NÁVOD K POUŽITÍ  
BEDIENUNGSANLEITUNG  
OPERATING INSTRUCTIONS  
MODE D'EMPLOI  
INSTRUKCJA UŻYTKOWANIA  
HASZNÁLATI ÚTMUTATÓ




## **SYNCHRO STF**

FLEXi FX 1101  
FLEXi FX 1111  
FOCUS FO 640A  
FOCUS FO 642A  
ANATOM AT 987A


1




2






3





4
















FLEXi FX 1101






FLEXi FX 1111










ANATOM AT 987A




**STOP!**  
**STOP!**






FLEXi FX 1101  
FLEXi FX 1111






FOCUS FO 642A  
ANATOM AT 987A

# FOCUS FO 642A

82 1F




83 3F





FLEXi FX 1101  
FLEXi FX 1111  
FOCUS FO 640A  
ANATOM AT 987A




91 1F






99 2F



86 3F



88 4F



# Rim<sup>®</sup>

**RIM-CZ spol. s r.o.**

Dr. E. Beneše 1015

765 02 Otrokovice

CZECH REPUBLIC

Tel.: +420 577 112 641, -640

Fax: +420 577 101 015

E-mail: [info@rim.cz](mailto:info@rim.cz)

[www.rim.cz](http://www.rim.cz)

